



KNOXBOX 3200 MOUNTING INSTRUCTIONS



Midlothian FMO Requirements for Knox Box mounting height: 66-72 inches above grade to top of Knox Box.

GENERAL MOUNTING INSTRUCTIONS


- CAUTION:** Be extremely careful when handling the KnoxBox 3200 prior to installation. When not mounted, the door will be OPEN. Always hold box and door securely to prevent door closing on fingers and causing injury.
Tamper Alert: If your KnoxBox has the Tamper Alert feature, remove the tamper alert assembly and set aside for installation after the box is mounted.
- Always mount your KnoxBox to a secure, solid wall, beam or post.
- Use a small level to plumb the box square.
- Position the KnoxBox with green mounting markers pointed up with the hinge on the right-hand side to allow for proper drainage. REMOVE the green markers after installation.
- Use at least four (4) Grade 5 or Grade 8 fasteners (carriage bolts, etc.) of 3/8" diameter. Units may also be welded into place. Mounting to solid beams or steel supports is best. Mounting face down from ceiling or overhanging area may cause contents to jam the lock.
- For proper weatherproofing, caulk the back of box across top and down each side. Leave the bottom open for drainage.
- Use of a professional locksmith or alarm product installer is highly recommended.

DOOR REMOVAL AND ADJUSTMENT:

If the door must be removed and the door has a rounded powder coated hinge pin (see picture below), remove only the top and bottom hinge pin screw. Do not remove the three (3) hinge bracket screws as these are factory set for proper door alignment. When replacing the door, adjust hinge pin screws loose enough so that door swings freely. Thread locker (such as Loctite®) must be used on hinge pin screws.

For a KnoxBox 3200 that was manufactured before April 2013, the door will have a rounded powder coated hinge pin.


For a KnoxBox 3200 that has a flat, stainless steel hinge pin (models manufactured around or after April 2013), contact customer service and reference document OPE-I-GINS-10-226.




NOTE: Suggested minimum mounting height: 6' above ground

ATTENTION:

Installation of this product should be performed only by individuals skilled in the use of the tools and equipment necessary for installation. If you have any doubt concerning your competence or expertise, consult a qualified expert to perform the installation.



Surface Mounted Models



Recess Mounted Models

SURFACE MOUNT MODELS

Surface Mount models are designed for mounting on a flat wall. Do not mount face down from a ceiling or overhanging area. Install the Tamper Alert assembly after the box is mounted and check to see that the "box to wall" Tamper Alert plunger is properly depressed. A qualified alarm installer should perform alarm wiring, testing and adjusting.

RECESS MOUNT MODELS

Recess Mount models are designed for flush mounting. Do not mount face down from a ceiling or overhanging area. Units can be adapted to fit a variety of solid walls cored to a 6" diameter approximately 3 1/2" deep. A Recess Mounting Kit (RMK) is for new concrete or masonry walls under construction. Do not over tighten mounting bolts as this will distort the flange.

Install the Tamper Alert assembly after the box is mounted. Pull wiring tight so that any attempts to force the box out of the wall will break the wire or pull the terminals loose. A qualified alarm installer should perform alarm wiring, testing and adjusting.

If installing the box on a thin or hollow wall, use a solid backing (like 3/8" steel plate fastened to solid studs on both sides) for secure mounting. Mounting to solid beams or steel support is best.